


**COALBROOK**




**5 HOLE DECK MOUNTED BATH FILLER  
INSTALLATION**

---

BA2006 | DC2006 | DO2006 | ZU2006

## SPOUT INSTALLATION DIAGRAM




1. When necessary, drill a suitable size hole in the mounting surface to suit the threaded tail of the spout (A) which is  $\varnothing 21$ .
2. Pass the threaded tail of the spout (A) through the hole in the mounting surface. Align the spout.
3. Locate both washers (B) onto the threaded tail. Ensure that the rubber washer is assembled first so that it comes into direct contact with the mounting surface.
4. Screw the backnut (C) onto the threaded tail and tighten to secure the spout. Do not over tighten.

**COALBROOK**

www.coalbrookuk.co.uk | info@coalbrookuk.co.uk

## FLOW VALVE INSTALLATION DIAGRAM (STEPS 1 - 3)




1. When necessary, drill a suitable size hole in the mounting surface to suit the flow valve body (D) which is  $\varnothing 33$ .
2. Locate the flow valve body (D) through the hole in the mounting surface.
3. Screw the deck plate (E) onto the top of the flow valve until both components come to a natural stop.

Suitable access is required underneath the mounting surface as the flow cartridge can only be serviced by removing the side valve assembly from its mounted position.

**COALBROOK**

www.coalbrookuk.co.uk | info@coalbrookuk.co.uk


## FLOW VALVE INSTALLATION DIAGRAM (STEPS 4- 10)



4. Rotate the flow valve body so that the side outlet port is facing the required direction for connection.
5. Once the flow valve orientation is confirmed, screw the backnut (F) to secure the flow valve body in place. Do not over tighten.
6. Before assembling trim components, the spline adaptor (G) needs to be located onto the exposed cartridge spindle and secured using the provided screw.
7. For Domo trim assemblies, locate the lever hub (H) onto the spline adaptor and secure using the provided grub screw. The lever stem (I) can then be screwed into the hub.
8. For Decca trim assemblies, locate the handle base (J) onto the spline adaptor and secure using the provided grub screw.
9. The handle trim (K) can then be secured to the base using the two set screws.
10. Screw the cap (L) onto the trim to complete the installation.

**COALBROOK**



## FLOW VALVE INSTALLATION DIAGRAM (STEPS 11- 12)



11. For Bank trim assemblies, locate the Bank handle (M) onto the spline and secure by screwing the shroud into the flow valve.
12. For Zurich trim assemblies, locate the Zurich Lever (N) onto the spline and secure by screwing the shroud into the flow valve.

**COALBROOK**



**SPECIFICATION DIAGRAM (BA2006 & DC2006) (mm)**



**COALBROOK**

[www.coalbrookuk.co.uk](http://www.coalbrookuk.co.uk) | [info@coalbrookuk.co.uk](mailto:info@coalbrookuk.co.uk)

**SPECIFICATION DIAGRAM (DC2006 & ZU2006) (mm)**




**COALBROOK**

[www.coalbrookuk.co.uk](http://www.coalbrookuk.co.uk) | [info@coalbrookuk.co.uk](mailto:info@coalbrookuk.co.uk)


## TYPICAL FLOW RATES – SPOUT

Flow rates shown are free-flowing and may vary subject to restrictions created by installation, pipework layout or application



Water Pressure (Bar)	Spout (Litres/minute)
0.5	12.1
1.0	16.9
2.0	24.4
3.0	31.1
4.0	35.3
5.0	-

## TYPICAL FLOW RATES – HANDSHOWER



Water Pressure (Bar)	Handshower (Litres/minute)
0.5	4.7
1.0	6.9
2.0	10.2
3.0	13.0
4.0	15.7
5.0	18.7





**COALBROOK**

Whilst every effort is made to ensure the accuracy of these, they are subject to change without notice as part of the company's product development process. The use of trademarks, product design and artwork is subject to licence or agreement. The design registrations, trademark registrations and copyrights are protected by law and the use or reproduction outside the terms of an agreement is prohibited.

The right to modify designs and dimensions is reserved. E & O.E.

v1.0822

**COALBROOK**

[www.coalbrookuk.co.uk](http://www.coalbrookuk.co.uk) | [info@coalbrookuk.co.uk](mailto:info@coalbrookuk.co.uk)